


Linkind

User Manual

Linkind Smart Solar Spotlight SL5C




HOW-TO VIDEOS

CONTENT English

SPECIFICATION	01
INTRODUCTION	01
PACKAGE CONTENTS	01
INSTALLATION	02
OPERATION	02
BUTTON CONTROL	03
CONNECTING TO THE AiDot APP	03
CONTROLLING SL5C WITH THE AiDOT APP	04
GROUP CONTROL	06
SYNC LIGHTS WITH MUSIC	06
TROUBLESHOOTING	07
GENERAL TIPS	08


SPECIFICATION



LEDs	16
Durability	Dust and Water Resistant
Temperature Range	14°F - 104°F (-10°C - 40°C)
Housing Material	ABS
Beam Angle	90°

INTRODUCTION


Linkind Smart Solar Spotlight SL5C seamlessly combines convenience and intelligence. Its plug-and-play wire-free solar-powered design makes setup a breeze, and the adjustable angle allows for easy aiming so you can highlight your yard in all the right places. Enjoy smart features such as group control and dynamic lighting. SL5C can sense the available light to turn on automatically from dusk until dawn.



PACKAGE CONTENTS

- A. 2/4/8 x Linkind Smart Solar Spotlight SL5C
- B. 2/4/8 x Ground Stake
- C. 2/4/8 x Mounting Rod
- D. 2/4/8 x Locking Bolt
- E. 6/12/24 x Wall Anchor
- F. 6/12/24 x Screw
- G. 1x User Manual

***Note:** Quantities listed for the 2, 4, and 8 packs. Check the corresponding quantity for the pack size you purchased.




INSTALLATION

Whichever installation method you choose, ensure the location where the light is installed receives sufficient sunlight daily to keep the device charged.

Method 1: Ground Stake


- ① Connect the ground stake to the mounting rod. Attach the light to the mounting rod, set it to the desired angle, then secure it with the locking bolt.
- ② Insert the ground stake vertically into the ground.



Note: Please insert the knob from the correct side as shown above.

Method 2: Wall Mounted

- ① If mounting to a wall made of a hard material such as concrete, drill two holes and insert the wall anchors into the holes, this may be skipped for soft materials such as wood. Then position the mounting rod and use the screws to secure it in place.
- ② Attach the light to the mounting rod, set it to the desired angle, then secure it with the locking bolt.



Note: Please insert the knob from the correct side as shown above.

OPERATION

By default, the light will be off. Press the button to turn it on and to adjust modes.



BUTTON CONTROL

Press the button located at the bottom of SL5C to cycle through red, orange, yellow, green, blue, cyan, purple, 2,700K white, 6,500K white and off.

Note:

If you are using SL5C during the day, you may find that it turns off after a short time. By default, this time is 30 seconds. To keep the light on during daylight, cover the solar panel, which will also cover the luminance sensor.



CONNECTING TO THE AiDot APP

Steps to connect SL5C to the AiDot app:



1. Download the AiDot app by scanning the QR code below or searching for AiDot on the App Store or Google Play.



Google, Google Home and Google Play are trademarks of Google LLC.

2. Open the AiDot app and sign in, or create a new account.

3. Make sure Bluetooth is enabled on your mobile device.



4. Press and hold the button on the light until it enters pairing mode. The light will cycle between warm white and cool white to indicate this.

5. Tap "Add Device" or the "+" button. You can also use the "Nearby" option, which will search for nearby AiDot products in pairing mode. The app may ask for Bluetooth permissions on your phone. Allow these to connect to SL5C.

6. If you can't find your SL5C in the app, ensure it's in pairing mode as described in step 4. Then, try connecting again using the app.

Note:

SL5C can be controlled from a distance of up to 98 ft. (30 m) when unobstructed.


CONTROLLING SL5C WITH THE AIDOT APP

With the AiDot app you can control:


- a) Power: Turn SL5C on or off.
- b) Brightness: Adjust the light level of SL5C.



c) Presets: Activate various light effects, themes, and scenes.




d) White: Vary the temperature of SL5C's white light from 2,700K to 6,500K.



e) Color: Choose a color for all or each of your SL5C lights. You can also create personalized lighting effects.

SL5C offers two operating modes:

1. Luminance Detection: SL5C will automatically turn on at dusk and remains on until dawn. It stays off during the daylight hours and collects solar power for the next night.



2. Light Mode: SL5C remains on, providing constant illumination of your space, suitable for scenarios requiring all-day lighting.



GROUP CONTROL

Group control synchronizes grouped SL5C lights by:


1. Activating preset lighting effects across the whole group.
2. Synchronizing light color and temperature for coordinated lighting.

Note: If after creating a group some products only light up for a limited time or fail to sync, your devices may be in different modes. Set each device within the group to the same mode.




SYNC LIGHTS WITH MUSIC

1. You can find the Sync with Music option from the device control page where it appears as "Music".



2. Using this feature, you can choose from presets or create your own lighting effects that match the music being played.

Note: To use the Sync Lights with Music feature, you must grant Bluetooth permissions to the AiDot app and ensure your mobile device's Bluetooth is turned on.



TROUBLESHOOTING

Issue	Troubleshooting Steps
The light fails to turn on.	<ol style="list-style-type: none">1. Make sure you hear a click sound when the button is pressed.2. Check for nearby light sources. When in luminance detection mode, a nearby light source that is bright enough may prevent your SL5C from automatically turning on. You can try relocating your SL5C, eliminating the nearby light source, or as a temporary solution you can cover the solar panel of your SL5C, which will also cover the luminance sensor, activating the light regardless of nearby light sources.
The light output from my SL5C is dim.	<ol style="list-style-type: none">1. The brightness of the light is reduced when the battery level is low. The device will need to be charged before resuming its regular light output.2. You can check the battery level of your SL5C through the AiDot app.
My SL5Cs turn on at different times.	Each SL5C automatically lights up when the ambient light in its area drops below 20 lux. Slight differences in the light level at the location of each light can cause them to activate and deactivate at different times. This is normal and expected behavior when set to luminance detection mode.

GENERAL TIPS

1. Smart Solar Spotlights offer various installation methods, including wall mounting and ground insertion. During installation, ensure that the solar panel is not obstructed in any way to ensure adequate charging and smooth operation.
2. To prolong the lifespan of your light's battery, install it in a place with direct sunlight that covers the entire solar panel. Let each light charge for 48 hours before its first use.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Linkind

Our goal is to bring you the best shopping experience.

If you have any questions about our product, please feel free to contact us. Our customer service is right here to resolve the case.

☎ 1 (877) 770-5727 Mon.- Fri., 8:00AM- 5:00 PM(PT)

✉ service@linkind.com

🌐 <http://www.linkind.com>

📘 <https://www.facebook.com/linkind.lights>

📷 <https://www.instagram.com/linkindofficial>

▶ <https://www.youtube.com/@linkindofficial>

RoHS CE



Made in China